

PRESE A STAFFA - CLAMP SADDLES
COLLIER DE PRISE - COLLARIN DE TOMA
ANBOHRSCHELLEN - ЗАЖИМНЫЕ ХОМУТЫ ИЗ ПОЛИПРОПИЛЕНА

COD. 1019



PRESA A STAFFA
 CLAMP SADDLE
 COLLIER DE PRISE
 COLLARIN DE TOMA
 ANBOHRSCHELLEN
 СЕДЛО ЗАЖИМНОЕ

COD	DIM	N.BUL.	PACK B
1019025002001	25x1/2"	2	180
1019025003001	25x3/4"	2	180
1019032002001	32x1/2"	2	140
1019032003001	32x3/4"	2	140
1019032004001	32x1"	2	140
1019040002001	40x1/2"	2	110
1019040003001	40x3/4"	2	110
1019040004001	40x1"	2	110
1019050002001	50x1/2"	4	80
1019050003001	50x3/4"	4	80
1019050004001	50x1"	4	80
1019050005001	50x1 1/4"	4	80
1019063002001	63x1/2"	4	55
1019063003001	63x3/4"	4	55
1019063004001	63x1"	4	55
1019063005001	63x1 1/4"	4	55
1019063006001	63x1 1/2"	4	55
1019075002001	75x1/2"	4	40
1019075003001	75x3/4"	4	40
1019075004001	75x1"	4	40
1019075005001	75x1 1/4"	4	40
1019075006001	75x1 1/2"	4	40
1019075007001	75x2"	4	40
1019090002001	90x1/2"	4	30
1019090003001	90x3/4"	4	30
1019090004001	90x1"	4	30
1019090005001	90x1 1/4"	4	30
1019090006001	90x1 1/2"	4	30
1019090007001	90x2"	4	30
1019110002001	110x1/2"	4	19
1019110003001	110x3/4"	4	19
1019110004001	110x1"	4	19
1019110005001	110x1 1/4"	4	19
1019110006001	110x1 1/2"	4	19
1019110007001	110x2"	4	19
1019125002001	125x1/2"	6	12
1019125003001	125x3/4"	6	12
1019125004001	125x1"	6	12
1019125005001	125x1 1/4"	6	12
1019125006001	125x1 1/2"	6	12
1019125007001	125x2"	6	12
1019160003001	*160x3/4"	6	13
1019160004001	*160x1"	6	13
1019160005001	*160x1 1/4"	6	13
1019160006001	*160x1 1/2"	6	13
1019160007001	*160x2"	6	13
1019160008001	*160x2 1/2"	6	10
1019160009001	*160x3"	6	9
1019160010001	*160x4"	6	9
1019200003001	*200x3/4"	6	11
1019200004001	*200x1"	6	11
1019200005001	*200x1 1/4"	6	11
1019200006001	*200x1 1/2"	6	11
1019200007001	*200x2"	6	11
1019200008001	*200x2 1/2"	6	10
1019200009001	*200x3"	6	9
1019200010001	*200x4"	6	8

* PN 6 bar